




# RRE & RRE-C - SERIES ELECTRIC RANGE



81924

<p>POWER DIST. BLOCK</p> <p>1</p>	<p>GROUND LUG</p> <p>2</p>	<p>CONTROL SWITCH</p> <p>13</p>	<p>THERMOSTAT</p> <p>14</p>	<p>KNOB THERMOSTAT</p> <p>18</p>	<p>KNOB SWITCH</p> <p>19</p>	<p>INDICATOR LIGHT</p> <p>20</p>	<p>CIRCUIT BREAKER</p> <p>33</p>	<p>DOOR SWITCH</p> <p>34</p>
-----------------------------------	----------------------------	---------------------------------	-----------------------------	----------------------------------	------------------------------	----------------------------------	----------------------------------	------------------------------

RR-E SERIES - ELECTRIC RANGE		
ITEM NO.	PART NO.	
1	2584	Power Distribution Block, 3 Pole
2	2585	Ground Lug
3	34025	24" High front & high back assembly
	34026	36" High front & high back assembly
	34027	48" High front & high back assembly
	34028	60" High front & high back assembly
	34029	72" High front & high back assembly
4	40495	Bracket, Burner MTG
5	40494	Panel, Top Elements MTG
6	2577	Hot Plate Element, <b>208V</b>
	2578	Hot Plate Element, <b>240V</b>
7	30131	24" Shelf
	30148	36" Shelf
	30169	48" Shelf
	30190	60" Shelf
	30211	72" Shelf
8	40983	12" Griddle Plate Wldmt, LH
	40975	24" Griddle Plate Wldmt, LH
	40985	36" Griddle Plate Wldmt, LH
9	4322	20" Oven Rack
	3210	26" Oven Rack
10	2580	Heater Element, Griddle, <b>208V</b>
	2581	Heater Element, Griddle, <b>240V</b>
11	41249	Plate LH, Griddle Element
	41250	Plate RH, Griddle Element
12	41251	Cover, Griddle Element
13	2574	Infinite Control Switch, <b>208V</b>
	2575	Infinite Control Switch, <b>240V</b>
14	2579	Thermostat
15	-	Control Panel, Model Specific, Contact Factory
16	3200	Rack Guide, sides
17	30406	Grease Can Wldmt
18	2597	Knob, Thermostat
19	2576	Knob, Infinite Swith
20	2595	Indicator Light, Red
21	30013	Door frame assy. (20" oven)
	30043	Door frame assy. (26 1/2" oven)
	30057	Door frame Assy, Convection oven.
22	30476	12" Crumb Tray, Hot plate
	30008	24" Crumb Tray, Hot plate
	30039	36" Crumb Tray, Hot plate
23	2570	Heater Element, Oven Top, <b>208V</b>
	2572	Heater Element, Oven Top, <b>240V</b>
24	40522	Top Oven Element MTG

RR-E SERIES - ELECTRIC RANGE		
ITEM NO.	PART NO.	
25	30041	Oven Bottom
26	40493	Bracket Heater MTG
27	30132	24" Oven door (complete)
	30159	36" Oven door (complete)
	30058	Convection Oven Door (complete)
28	30009	24" Kick plate
	30045	36" Kick plate
29	2571	Heater Element, Oven Bottom, <b>208V</b>
	2573	Heater Element, Oven Bottom, <b>240V</b>
30	1219	Cone Leg
31	2192	Caster, Swivel Plate, without break
	2193	Caster, Swivel Plate, with break
32	32976	Cover, Circuit Breaker RRE-36
33	2589	Circuit Breaker, 2 Pole
34	2539	Switch, Oven Door
35	30734	Door Switch Bracket
36	3098	Timer knob
37	2526	Switch, Power—3 Position
38	2525	Switch, Oven Fan High/Low
39	2523	Thermostat Dial
40	2522	Indicator Light
41	2579	Thermostat
42	2527	Manual timer & timer knob
43	30725	Control Panel R/H For 36" Range
44	2470	Control Panel Decal
45	2507	Hex Head Bolt (1/4-20 X 4)
46	30721	Blower Baffle
47	2505	Blower Spacer Tube
48	2503	Blower Wheel RR-C
49	30602	Motor Mount Weld Plate Assy.
50	5860	Motor