

Adande® Quick Start Guide



PLUGGING IN YOUR ADANDE

Your Adande® drawer should be connected to a 115V, single phase, 60 Hz, standard socket outlet supply. The drawer is connected to the mains supply with a detachable supply lead, one end of which is fitted with a standard 16 amp 3 pin plug. The other end of the supply lead, fitted with an appliance plug, ensure the P clip is secured in position as pictured below




Figure 1: Mains Connection Point



Figure 2: Daisy chain

The socket on the on the right hand side in figure 1 can be used to provide a mains supply to an additional Adande® drawer, utilizing a daisy chain cable as shown above in figure 2.

Ensure that the P clips are fitted to both the mains cable and daisy chain cable and fastened to the mains incomer panel.

DO NOT REMOVE ACCESS PANELS WITH THE ELECTRICAL SUPPLY CONNECTED.

THE DISPLAY CONTROLS

To adjust the temperature set point (*figure 3*) first unlock the keypad by tapping the unlock/scroll button twice, the light next to the unlock symbol will illuminate signifying that the keypad is now unlocked. Next tap the unlock/scroll button to display SP (set point) then tap the unlock/scroll button once more, now the current set point of the unit will be displayed. To adjust this simply either press the + or – button until the desired set point is displayed. The unit is now set. The display panel will automatically lock after 1 minute of inactivity.



Figure 3: Adande® Display Control Panel

DRAWER MAINTANANCE



The airflow through your Adande drawer is designed to deposit grease and dirt on the **outside** surface of the insulated container and **internal** surfaces of the drawer housing.

The insulated container must be removed from the drawer to clean these surfaces.

These dirt and grease deposits should be removed weekly using the following procedures:

- Clean the heated seal on a **weekly** or daily basis if required with a solution of warm water and mild detergent.
- The insulated container can be totally removed from the drawer for deep cleaning. Clean the insulated container with an anti-bacterial cleanser.
- Brush any loose dirt from the condenser Situated inside at the back left of the drawer.

NOTE: DO NOT USE SHARP UTENSILS

- Clean the steel surfaces with a polish cleaner.



NOTE: DO NOT USE STEEL PADS, WIRE BRUSHES, SCRAPERS OR CHLORIDE CLEANERS TO CLEAN STAINLESS STEEL, PAINTED SURFACES SHOULD BE CLEANED WITH MILD SOAP SOLUTIONS.

DO NOT PRESSURE WASH EQUIPMENT; THIS CAN DAMAGE THE ELECTRICAL COMPONENTS.